



Field Join Instructions MB-300 and MB-400 Series

Mad Matter MB-300 Series: (Aluminum Hinge)

1. Use an H-2 (5/64") or a 5/64" Allen Wrench Hex Key.
2. Install the driver bit in the tip of a cordless hand drill, screw gun, or use the wrench for manual removal.
3. Locate the pre-drilled female receiving rail as well as the punched male hinge portion of the rail on the underside of the rails.
4. Slide rails together until the pre-drilled hole and punch line up.
5. Using the provided set screws, insert set screw into the lined-up hole/punch to prevent sections from coming apart.

Mad Matter MB-400 Series: (Vinyl Hinge)

1. Use an H-3 (3/32") Hex Tip Bit Driver, or a 3/32" Allen Wrench Hex Key.
2. Install the driver bit in the tip of a cordless hand drill, screw gun, or use the wrench for manual removal.
3. Slide the hinged section of the mat into the female receiving rail.
4. Using the provided set screws, insert set screw into the end of the rail where the hinge was slid in to prevent sections from coming apart.